

FIG. 1





FIG. 2




FIG. 3




FIG. 3A

10072728.020702




FIG. 4




FIG. 5B




FIG. 5A
(PRIOR ART)






FIG. 6






FIG. 8B




FIG. 8A




FIG. 10




FIG. 10A




FIG. 11




FIG. 12

HERE IS A WINDOWS HEADER SHOWING THE COMMAND OPTIONS BANNER AS IT APPEARS ON THE SCREEN




FIG. 13A

DARK LINES HAVE BEEN ADDED TO DEFINE A TORQUE TROUGH ARROWS INDICATE MOTION IN X & Y AXES




FIG. 13B

CURVES BELOW SHOW TORQUE PROFILE FOR X & Y AXES MOVEMENTS INDICATED ABOVE.




FIG. 13C




FIG. 13D